

VS 2.3





sure to retain it for future reference. We hope that you will enjoy your AudioSource VS 2.3 Home Theater Speakers. Please take a few moments to read this manual, and be

Speaker Placement

The center channel speaker should be placed as close as possible to the TV, preferably either directly on top of or below it. This locks the sound to the picture. Place the surround speakers either behind or to the side of your listening position. An ideal position would be on the side walls, ear level, about two-thirds of the way back from the front of the room. This allows the speakers to aim directly at your ears and ing subwoofer may be added to create a true home theater environment. to simulate a full, five speaker home theater environment. Two front side speakers, similar to these surround speakers, and a bass enhanc-

Hooking Them Up

terminal on the corresponding component's speaker output terminals. The –, black or negative terminals must connect to the respective –, black or negative terminals. This is easy to do by observing the color, stripe, or ribbing that appears on the wire. be sure to retain the correct polarity. Attach the wire from the +, red, or positive terminal on one component to the +, red, or positive The spring-loaded speaker terminals on the back of the VS 2.3 can accommodate up to 16-gauge wire. When connecting the speakers,

Warranty

The VS 2.3 Home Speakers carry a two-year, transferable warranty. We also offer friendly, toll-free assistance at 1-800-HELP-115 (1-800-435-7115). You may also fax us anytime at 650-348-8083.

VS 2.3 Specifications

ConnectionsSpring-loaded binding clips	Sensitivity
Tweeter	Impedance8 ohms
Woofers	Power Capacity
Video Shielding Center Speaker	Frequency Response80 Hz - 20 KHz

AudioSource®

Burlingame, CA 94010 1327 North Carolan Avenue www.audiosource.net information@audiosource.net Tel. 650.348.8114 Fax 650.348.8083